




INSTALLATION INSTRUCTIONS

For Model 810 CHALLENGER EV


Your purchase of a Wolo's Challenger Horn System is a perfect choice to compliment your vehicle. Wolo's products are manufactured with the finest materials. Each horn is tested to insure it meets all manufacturing specification, before it is packaged. If you need help installing your new Wolo horn, our technicians are available to answer your questions, Monday through Friday from 9 AM to 4 PM EST by calling 1-888-550-HORN (4676).

HORN INSTALLATION (Fig. A)




1. Locate the desired area you wish to mount the dual trumpet air horn. For best results, the front of the horn should be unobstructed so that the sound can carry straight ahead.
2. Use the horn's rubber gasket as a template, mark hole locations and drill to sizes as shown in Fig. A.
3. Secure the horn with the hardware provided. Tighten screws evenly to provide a good watertight seal..
4. Secure the flexible inlet hose into the base of the horn. Do not remove the Teflon tape on the threaded end of the hose. The tape is used to help prevent air leaks. **CAUTION:** Avoid making any kinks or sharp bends in the flexible hose that will reduce airflow and alter the horn's sound.

COMPRESSOR INSTALLATION (Fig. B)




5. Locate an area in the engine compartment that is dry and safe from the heat of the exhaust manifold. Try to mount compressor as far to the front of vehicle as possible to provide a optimum airflow around compressor. **IMPORTANT!** Do not mount on a plastic fender well or on flexible material.
6. Using the compressors mounting as a template, mark hole locations and drill to size. 15/64". Secure the compressor to the mounting surface with the hardware provided.



TANK INSTALLATION (Fig. C)

7. Locate a convenient area in the vehicle to mount the air storage tank. **IMPORTANT!** When selecting a mounting location for the tank, make sure that the compressor metal braided hose is close enough to connect to the tanks brass female fitting.
8. Use the tanks mounting bracket as a template, mark the hole locations and drill 15/64" holes. Secure tank with hardware provided using the rubber gasket to prevent vibration noise.


HOSE INSTALLATION (Fig. D)



9. Connect the metal braided hose from the compressor to the tanks female brass fitting.
10. Using the 1/4" plastic high pressure hose provided, cut to size to connect the horn's flexible inlet hose to the electric solenoid mounted on the air tank.
11. Unscrew the brass-fitting nut from the flexible inlet hose. Place the brass-fitting nut onto the hose. Push the hose onto the male fitting of the flexible hose and tighten the brass nut. **CAUTION:** Do not over tighten nut.
12. Connect the other end of the hose to the tank's electric solenoid valve.

Follow the same procedure as above number 11.

WIRING TANK'S ELECTRIC SOLENOID VALVE (Fig. E)



13. Connect one of the electric solenoid wires to (+) 12 volt, such as battery, alternator, etc. Always use the 3-amp fuse provided.
14. Connect the other electric solenoid wire to horn switch provided.
15. Connect the other terminal of the horn switch to ground (-); secure to the (-) post of the vehicle battery or any metal body bolt that is clean of paint and rust.

WIRING COMPRESSOR (Fig . F)

16. The compressor's red wire is connected to (+) 12-volt power source using the fuse provided.

IMPORTANT! The red wire must be connected to a (+) 12-volt power source only when the vehicle ignition is turned on. This will protect your compressor from running continuously and being damaged if an air leak develops when the vehicle is not in operation. Suggested connection points are: blower motor, windshield wiper motor or accessory terminal on the fuse panel. Make sure the connection point has a wire that is as heavy as the compressor wire.

OPTIONAL: A switch can be installed into the compressor's red wire. This will permit the driver to turn-off the system if it is not required.


17. Remove the plastic cap covering the pressure switch on the side of the tank. The compressor's black wire is connected to one of the terminals of the pressure switch.

18. Connect the short black length of wire provided to the other terminal of the pressure switch.

19. The other end of the black wire is connected to ground; secure the wire's terminal to either the (-) side of vehicles battery or under any metal body bolt. Make sure that ground connection is free of rust and paint.

NOTE: The compressor is now ready to be used and will automatically start when the air pressure drops in the tank. The built-in regulator will automatically turn off the compressor when the tank's air pressure is approximately 110 p.s.i. If the compressor does not shut off after 4 minutes of running time, check all air hose connections for leaks. Use soapy water or bubble solution on each fitting while the compressor is pumping. Use a thread sealant if leak persists after tightening.

CAUTION: Do not touch compressor or fittings with bare hands during or immediately after usage, they will be hot.



WARRANTY

Wolo Manufacturing Corporation ("Wolo") warranties to the original purchaser, for three months from the date of purchase, that this product is free from defects in workmanship and materials. If there is such a proven defect, Wolo, at its option, will either repair or replace the item free of charge, if it is returned to Wolo within three months from the date of purchase together with proof of purchase as described below. Wolo reserves the right to inspect any defect prior to settling any warranty claim by repair or replacement. This warranty is limited as above provided and Wolo will not be responsible for fire or other casualty or accident, due to neglect, abuse, abnormal use, modifications, faulty installation of this product, or natural causes.

ANY EXPRESSED WARRANTY NOT PROVIDED HEREIN IS EXCLUDED AND DISCLAIMED. THE IMPLIED WARRANTIES OF MERCHANTABILITY AND OF FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY LIMITED TO A TERM OF THREE (3) MONTHS. UNDER NO CIRCUMSTANCES SHALL WOLO BE LIABLE TO PURCHASER OR ANY OTHER PERSON FOR ANY SPECIAL OR CONSEQUENTIAL DAMAGES, WHETHER ARISING OUT OF BREACH OF WARRANTY OR OTHERWISE.

To obtain warranty service, return the product prepaid, and include the original bill of sale showing the date of purchase. Provide with the return a brief description of the problem. Also, include with the return a check or money order in the amount of \$10.00 to cover return shipping. Mail to:

Wolo Manufacturing Corp.
One Saxwood Street, Deer Park, NY 11729
Attn: Warranty Service
E-mail: tech@wolo-mfg.com