

INSTALLATION INSTRUCTIONS

Models 350 & 360


Your purchase of a Wolo horn is a perfect choice to compliment your vehicle. Wolo's products are manufactured with the finest materials. Each horn is tested to ensure it meets all manufacturing specifications, before it is packaged. If you need help installing this product, our technicians are available to answer your questions, Monday through Friday from 9 AM to 4 PM EST by calling 1-888-550-HORN (4676).

MOUNTING:

1. Locate an area in the engine compartment that is dry and safe from the exhaust manifold heat.
2. Mount the speaker with the opening facing downward, this will help prevent dirt and water from entering into the speaker.
3. Using the mounting bracket as a template, mark the hole locations and, drill three-(3) 1/8" holes and secure the speaker with screws provided.

WIRING: Fig. 1

4. Red wire is connected to (+) 12 volts positive such as the battery, alternator, etc.
5. Black wire: is connected to the horn switch.
6. The horn switch's other terminal is connected to ground, (body of vehicle). **Important:** A good ground connection should be free of rust and paint. Installation is complete.
7. Always make sure that the horns electrical circuit is protected with a 3-amp fuse to protect the vehicle.



WARRANTY

Wolo Manufacturing Corporation ("Wolo") warranties to the original purchaser, for three months from the date of purchase, that this product is free from defects in workmanship and materials. If there is such a proven defect, Wolo, at its option, will either repair or replace the item free of charge, if it is returned to Wolo within three months from the date of purchase together with proof of purchase as described below. Wolo reserves the right to inspect any defect prior to settling any warranty claim by repair or replacement. This warranty is limited as above provided and Wolo will not be responsible for fire or other casualty or accident, due to neglect, abuse, abnormal use, modifications, faulty installation of this product, or natural causes.

ANY EXPRESSED WARRANTY NOT PROVIDED HEREIN IS EXCLUDED AND DISCLAIMED. THE IMPLIED WARRANTIES OF MERCHANTABILITY AND OF FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY LIMITED TO A TERM OF THREE (3) MONTHS. UNDER NO CIRCUMSTANCES SHALL WOLO BE LIABLE TO PURCHASER OR ANY OTHER PERSON FOR ANY SPECIAL OR CONSEQUENTIAL DAMAGES, WHETHER ARISING OUT OF BREACH OF WARRANTY OR OTHERWISE.

To obtain warranty service, return the product prepaid, and include the original bill of sale showing the date of purchase. Provide with the return a brief description of the problem. Also, include with the return a check or money order in the amount of \$10.00 to cover return shipping. Mail to:

Wolo Manufacturing Corp. • One Saxwood Street, Deer Park, NY 11729 • Attn: Warranty Service
E-mail: tech@wolo-mfg.com